

Thank you for purchasing this ALPHA COMPETITION product for your car!

Installation of this product should only be performed by persons experienced with installation of aftermarket performance parts and proper operation of high performance vehicles. If vehicle needs to be raised off the ground for installation, the installer must use proper jacks, jack-stands and/or a professional vehicle hoist for safety of the installer and to protect property. If the vehicle is lifted improperly, serious injury or death may occur! Please read through all instructions before performing any portion of installation. If you have any questions, please contact our tech department prior to starting installation. We can be reached by the following email:

support@alpha-competition.com

GENERAL MODIFICATION NOTE

Modifications to any vehicle can change the handling and performance. As with any vehicle extreme care must be used to prevent loss of control or roll-over during sharp turns or abrupt maneuvers. Always wear seatbelts, and drive safely, recognizing that reduced speeds and specialized driving techniques may be required. Failure to drive a vehicle safely may result in serious injury or death. Do not drive a vehicle unless you are familiar with its unique handling characteristics and are confident of your ability to maintain control under all driving conditions. Some modifications (and combinations of modifications) are not recommended and may not be permitted in your country.

Consult the owner's manual, service manual, instructions accompanying these products, and local laws before purchasing and installing these modifications.

You are responsible for the legality and safety of the vehicle you modify using these components!



ALPHA COMPETITION Quick Shifter Adapter

Installation instructions



img 1



img 2

1. Remove the shifter bezel before pulling up the lower part. (img 1)

2. Remove the T25 Torx screws and 5mm Hex Key bolts from the surround's edge. (img 2)



img 3



img 4



img 5



img 6



img 7

3. Remove the T25 Torx screw from passenger side lower panel. (*img 3*)

4. Removed exposed T25 Torx screw. (*img 4*)

5. Remove the T25 Torx screw from passenger side lower panel. (*img 5*)

6. Removed exposed T25 Torx screw (*img 6*)

7. Remove the main lower console by gently pulling it out. (*img 7*)



img 8

8. Using a flat screwdriver pry off cable socket end from shift lever (*img 8*)



img 9

9. Install Alpha Competition adapter onto lever, like show on (*img 9*)



img 10

10. Install rear plate with M6 screws. (*img 10*)



img 11

11. Grease ball and push on cable socket. Test shifting thru gears (*img 11*)

12. Re-install center console in reverse of disassembly and test again shifting thru gears.