



INSTALLATION GUIDE

BMW Billet Oil Filter Housing
CTS-HW-271



20630 Mufford Crescent, Unit #309
Langley, British Columbia V2Y 2V9

www.CTSTURBO.com

WHAT IS INCLUDED

1. Billet Oil Filter Housing



TOOLS REQUIRED

1. 19mm Socket
2. Oil Filter Removal tool
3. Pick/Screwdriver to remove O-Ring
4. Ratchet
5. Rags

NOTES

Vehicle used in this guide is a 2007 VW GTI. Always make sure the car is safe to work on. Do not work on a hot motor. We do not accept any liability for incorrect installation or damage during the install.

STEP 1

Loosen Oil Filter



STEP 2

Slowly remove Oil Filter, allow the filter to drain oil before removing to avoid any mess.



STEP 3


Remove the O-ring from the
OEM Filter Housing



STEP 4

Install the O-Ring onto the
new Billet housing

Smear a small amount of oil
on the o-ring



STEP 5

Remove the Baffle from the OEM housing by leveraging it forward from it's base.

Be as gentle as possible to avoid losing any parts of the assembly when it pops out.

**STEP 6**

This is how the baffle looks when removed.



STEP 7

Install the baffle into the Billet housing by pressing it into the inner retaining ring.

(The assembly is friction-fit)

**STEP 8**

Install the new billet housing with a fresh Oil Filter

Use a 19mm Socket to tighten.



STEP 9
Your Done!

