


SUBARU STI BAFFLED OIL CATCH CAN SYSTEM, 2008-2014

INSTALLATION DIAGRAM

*This install diagram is strictly for the Subaru STI, routing is different for WRX. Please refer to WRX diagram for details.

LEGEND

- Dirty "In" Lines
- Clean "Out" Lines
- Supplied 1/2" Cap
-  Overlapping Hoses
-  1/2" X 3/8" Npt 90° Adapter

NUMBER KEY

- 1- Dirty 3/8" ID Curved Hose
- 2- Clean 3/8" ID Curved Hose
- 3- Dirty 1/2" ID Curved Hose
- 4- Dirty 1/2" ID Short Striaight Hose
- 5- Dirty 1/2" Long Str Hose
- 6- Clean 1/2" ID Curved Hose

