
Prosport Inc. Performance Oil Pressure Gauge Amber/White Display (270° Scale)



Wiring Instructions


Red- 12v Accessory power Black-Ground White- 12v accessory power Orange- Headlight switch (12v power when lights are turned on)

Sensor:

G Terminal- Connect green wire from gauge to this terminal WK Terminal- Run wire from terminal to ground


Lighting Diagram

Night Time	Installation
White	White — Connect to acc. Power Amber — Do not connect
Amber	White — Do not connect Amber — Connect to acc. Power
Amber	White— Connect to acc. Power Amber — Connect to parking lamp
White	Amber — Connect to acc. Power White — Connect to parking lamp
	White Amber Amber White




Do not over tighten bolts when installing U bracket. Doing so will cause damage to movement inside.


Performance Oil/ Water Temperature Gauge Amber/White Display (270° Scale)




Wiring Instructions

Red- 12v Accessory power Black-Ground White- 12v accessory power Orange- Headlight switch (12v power when lights are turned on) Green-Temp Sensor







installing U bracket. Doing so will cause damage to movement inside.