
Prosport inc. Premium Oil Pressure Gauge Amber/White Display (270° Scale)



Upper radiator

Setting warning / Mute Feature

To set the warning feature:
After the opening ceremony is complete, Press and hold the button down for approx 5 seconds until the pointer begins to blink. Release button. Push and hold button to move quickly across the scale or Toggle button to move pointer in small increments. Once you have the pointer were you want it, wait 5 seconds to "set" and pointer will stop blinking

Mute feature:

- 1.) With ignition key in off position, press and hold button-
- Turn Ignition on, wait for pointer to come to a rest then release button.
- 2.) To turn sound back on-Repeat step 1

- Peak recall

 1.) Push button one time to recall peak level. The Blue light will come on when gauge is in recall mode. The pointer will rise to the Highest level attained by the gauge and remain there approximatley 5 seconds.
- 2.) To reset peak level: While in peak mode (blue light is on) press and hold button down


Color Diagram

| Day Time | Night Time | Installation | Double sided tape VISOR |
|-------------|-------------|--|---|
| White color | White color | White color — Connect to acc. Power Amber color — Do not connect | Gauge U1-02in BUFFER METER CLIPS HOLDER |
| Amber color | Amber color | White color—— Do not connect Amber color—— Connect to acc. Power | |
| White color | Amber color | White color — Connect to acc. Power Amber color — Connect to parking lamp | |
| Amber color | White color | Amber color — Connect to acc. Power White color — Connect to parking lamp | |

Do not over tighten bolts when installing U bracket. Doing so will

cause damage to movement inside

Premium Oil/ Water Temperature Gauge Amber/White Display (270° Scale)



WWW.PROSPORTGAUGES.COM

You may use teflon tape but be sure not to get any into

Optional radiator hose adapter