




For additional install information please visit [www.p3gauges.com/install](http://www.p3gauges.com/install)

# Subaru BRZ / Toyota GR86 Display Install Guide



**1** Use a screwdriver or pry tool to disconnect the 3 clips on the vent trim and then remove vent trim from housing



**2** Remove screw from back of vent housing



**3** Remove internal mechanism from vent housing



**4** Insert display ribbon cable as shown. Note the orientation of the notch in the vent (12 O'Clock Position)

**WARRANTY & LIABILITY:** Neither P3 Cars, nor its dealers or agents shall be liable in any way, for any damage, loss, injury or other claims, resulting from the installation or use of this product. By purchasing or installing this product, you assume all liability of any kind connected with the use and/or application of this product. If you are unsure that you can safely install and use this product, consult a qualified installer or mechanic. The warranty on this product covers only the product itself for a period of 6 months from the date of purchase, and it will be at our discretion to repair or replace the affected parts. No user serviceable parts inside. Warranty will be voided if product shows physical damage.



**5** Install the display into the vent housing as shown, making sure the notch is at the top of the display



**6** Insert #6 2 inch screw (provided) into hole in back of vent housing



For additional install information please visit [www.p3gauges.com/install](http://www.p3gauges.com/install)



**7** Tighten screw until head touches vent housing (do not over tighten)



**8** Snap the trim back onto the vent housing making sure to line up the notch at the top of each part



You can now install the gauge into your vehicle.

**WARRANTY & LIABILITY:** Neither P3 Cars, nor its dealers or agents shall be liable in any way, for any damage, loss, injury or other claims, resulting from the installation or use of this product. By purchasing or installing this product, you assume all liability of any kind connected with the use and/or application of this product. If you are unsure that you can safely install and use this product, consult a qualified installer or mechanic. The warranty on this product covers only the product itself for a period of 6 months from the date of purchase, and it will be at our discretion to repair or replace the affected parts. No user serviceable parts inside. Warranty will be voided if product shows physical damage.